Please read and understand this instruction manual thoroughly before using this product.

For Mini-Z MR-03VE Series models VE Manager Software N	Instruction Manual
This product is used to connect Mini-Z MR-03VE series models to a personal computer, and through a special software program it can adjust steering and throttle settings. *Standard settings are set at time of shipment.	 Before Use KYOSHO CORPORATION accepts no responsibility for any consequences resulting from the use of this product. By using this product the user accepts full responsibility. Even if KYOSHO CORPORATION receives a report relating to malfunction or other issues, it gives no undertaking to repair, modify or add functionality to the product.
 System Requirements Computer with Microsoft Windows XP(SP2~) or Windows Vista(32/64bit), Windows 7(32/64bit) and one available USB port (1.1 or 2.0). It needs ICS USB adapter HS driver that KONDO kagaku released under using high-speed system. Please download and install (http://www.kopropo.co.jp/sys/archives/2933). CD-ROM Drive 	 Company or organization names, and product names referred to in this instruction manual are the trademarks or registered trademarks of the respective companies or organizations. When used with Mini-Z ASF 2.4GHz series or dNaNo FX series models, this software is provided at no charge. However, the copyright of this software is owned by Kondo Kagaku Corporation and therefore unauthorized copying, sharing or reverse engineering or similar activities are prohibited. Modifications may be made due to improved display screen performance.

Required for OperationMini-Z MR-03VE chassis



•I.C.S USB adapter set (No.82080) or I.C.S USB adapter HS made by KO.



Preparations required before use

Connect ICS USB adapter and install the software driver

(This enables the ICS USB Adapter to work on your computer)

- Plug the ICS USB Adapter into the USB port on the computer. The USB adapter may not function properly if using a USB hub or a USB extension cable.
- If there is more than one USB port on your computer, try to use the same USB port for the USB Adapter each time. Using a different port may require the software driver to be re-installed.
- These instructions relate to standard computer screen settings and may differ according to your computer setup or customized screen settings.

1.Connect the ICS USB Adapter directly to the USB port on the computer.



· 'Found New Hardware Wizard' should appear in a text balloon on the screen.



- 2. Click on the text balloon.
- A window with the Found New Hardware Wizard should then be displayed.
- 3. Choose 'No, do not connect at this time' and then click Next.



If your computer is not connected to the internet, the screen to the left will not be displayed. Proceed to step 4. 4. Choose 'Install from a list or specific location' and click Next.



5. Choose 'Include this location in the search' and click 'Browse'. Insert the CD-ROM into the CD-ROM <u>drive (or DVD-ROM) and choose the folder named 'Driver</u>' and click Next.



- 6.Click 'Continue' .
- Installation will commence.



In some cases 'Insert disk' or 'File Required' messages are displayed during installation. If this occurs, please follow the steps below. ① If 'Insert Disk' message window appears, click OK.

- ② If 'File Required' message window appears, click 'Browse' and then after clicking the 'Driver' folder on the CD-ROM, click 'ftdibus.sys' or 'ftser2k.sys' then click 'Open'.
- Please refer to this instruction manual and the steps that follow to complete installation.

- 7. Click 'Finish'
- The installation may take a few minutes to finish. After installation is complete, the screen shown below is displayed.



- 8. After completing installation of the ICS USB Adapter, perform the installation of the USB Serial Port driver.
- Just as in step 2 the balloon text message 'Found New Hardware' should appear. Click the balloon text and repeat steps 2 7. The message windows displayed may be slightly different, but the steps are the same.



Confirm COM port setting

(Checking the ICS USB Adapter has been properly installed)

- 1.Click : Start > Control Panel > Performance & Maintenance > System and then click the 'Hardware' tab.
- Depending on your computer's settings, 'Performance & Maintenance' option may not be displayed. If this is the case, select 'System'.



- 2. Click 'Device Manager'.
- Device Manager window is displayed.

Device Manager Image: Image: <t< th=""><th>netal</th><th>Computer Name</th><th>Hardware</th><th>Advanced</th><th>Bemote</th></t<>	netal	Computer Name	Hardware	Advanced	Bemote
Device Manager Image: Image: <t< td=""><td>lordi</td><td>compater Hame</td><td></td><td>Advanced</td><td>Homoto</td></t<>	lordi	compater Hame		Advanced	Homoto
The Device Manager lists all the hardware devices installed on your computer. Use the Device Manager to change the properties of any device. Device Manager Divers Driver Signing lets you make sure that installed drivers are compatible with Windows: Windows Update lets you set u how Windows connects to Windows Update for drivers. Driver Signing Windows Update Hardware Profiles Hardware profiles provide a way for you to set up and stor different hardware configurations.	Devid	e Manager			
Drivers Driver Signing lets you make sure that installed drivers are compatible with Windows. Windows Update lets you set u how Windows connects to Windows Update for drivers. Driver Signing Windows Update Hardware Profiles Hardware Profiles provide a way for you to set up and stor different hardware configurations. Hardware Profiles		The Device M on your comp properties of a	lanager lists uter. Use the any device.	all the hardw Device Mar	are devices inst ager to change Device Manage
Driver Signing lets you make sure that installed drivers are compatible with Windows. Windows Update lets you set u how Windows connects to Windows Update for drivers. Driver Signing Windows Update Hardware Profiles Hardware Profiles provide a way for you to set up and stor different hardware configurations. Hardware Profiles	Drive	rs			
Driver Signing Windows Update Hardware Profiles Hardware profiles provide a way for you to set up and stor different hardware configurations. Hardware Profiles		Driver Signing compatible wit	lets you mai th Windows.	ke sure that i Windows Up	nstalled drivers a idate lets you se
Hardware Profiles Hardware profiles provide a way for you to set up and stor different hardware configurations. Hardware Profiles		how Windows	s connects to	Windows U	pdate for drivers
Hardware Profiles		how Windows	s connects to Signing		pdate for drivers /indows Update
	Hardy	how Windows Driver ware Profiles Hardware pro different hardw	s connects to Signing files provide ware configu	a way for you rations.	pdate for drivers /indows Update i to set up and s

3. Double-click 'Port' and confirm that 'ICS ADAPTER (COM 'X")' is displayed.



- X' indicates the number that the software will use. Write it down as it will need to be referred to later. These instructions use the number 3 as an example for 'X', but your computer or USB port may assign a different number. Make sure to check the port number used on your computer.
- If the ICS USB Adapter is not installed correctly, it will not be displayed. In this case, repeat the 'ICS USB Adapter connection and driver installation'.

Downloading the Software

NOTICE

• The software is subject to change for upgrade work. Download the latest software with referring "How to download" on the next page.

\diamondsuit Special Software Program





Visit below URL and download the software on your computer. After downloaded, please check above both software is in same folder.

• Mini-Z ASF 2.4GHz Series <u>http://www.kyosho.com/mini-z-support/</u> (Mini-Z series support home page)

(Above URL may be subject to change.)

- 1.After the download double click the software icon(📷 🖤)on downloaded folder.
- Install window is displayed, click Next ".

MR-03 VE ICS Manager		
Welcome to the MR-0 Wizard	3 VE ICS Manager Setup	Ş
The installer will guide you through th computer.	e steps required to install MR-03 VE ICS Manag	per on your
WARNING: This computer program i Unauthorized duplication or detabuti or caninal penalties, and will be proo	is protected by copyright tern and international to on of this program, or any position of a may read	ealies. Lin severe civil e law.
	Cancel (1995)	Next >

2. Finish the install as display, install will be success when the below displayed .

MR-03 VE ICS Manager	9		
MR-03 VE ICS Manager has been	successfully installed.		
Click "Close" to exit.			
Please use Windows Lindate to ch	eck for any critical upda	ites to the NET Fram	ework
		K Back	Close

3. Confirm that the saved folder is indicated by the icon below.



How to connect the model to the computer and use the software

1. Connect the Extension Cable to the ICS USB Adapter



2. Connect the I.C.S. Cable to the Extension Cable.



- 3. Connect the I.C.S. Cable to the I.C.S. Connector on the (Mini-Z or dNaNo) model.
- The connectors are designed to prevent reverse connection. If connection seems too tight, disconnect and check the direction of the connectors, then re-connect.



- 4. While pushing the pairing switch down, turn the power ON.
- Check that the Pairing LED indicator is on. When the LED indicator is on, data is able to be transmitted. If the LED indicator is not on, repeat step 4. For the location of the LED indicator on the chassis, refer to the instruction manual for each model.



- 5. Start the software program that was installed.
- Mini-Z MR-03VE Series
 -Double-click "MR-03 VE ICS Manager"



Explanation of Software Program Interface

When each function of the software is used, the following window is displayed.

- First complete the 'COM(M)' settings (refer to 'COM(M)').
- The screen displayed below is the default setting at time of shipment.



If it has a cursor to each item, explanation of the item will be displayed here. Please refer to it.

First complete the 'COM(M)' settings (refer to 'COM(M)')

Button Names and Functions



Write

The connection settings displayed now will be saved on the chassis. As these settings will overwrite the existing settings, saving the existing settings from the chassis is recommended.



Read

Saves the setting data from the chassis to the computer it is connected to. Please note that saving data will overwrite any data that is displayed on the screen.



Reset

Returns all settings back to the factory default settings. Remember this when using this function. *For all settings back to factory defalt, please click "Write" after clicking "Reset".



Load

Displays the data saved on the computer's hard disk.



Save

Saves the setting data currently displayed on the screen to the computer's hard disk. This will not save any setting data onto the chassis. You can only save one set of data on the chassis at a time. Keeping multiple sets of data saved on the computer is recommended.



Exit

Closes the software program.