X-SPEED モーター Type S No. DNW108

dNano FXシリーズ専用に開発された高性能モーターです。 下記の注意事項を守って正しく使用してください。



- ●このモーターはdNaNo FXシリーズ以外には使用しないでください。
- ●モーターの取付け・取外しについては、車体の取扱説明書を良く お読みになってください。
- ●高速走行に対応するためにボールベアリングセット (No. DNW101)、 ジャイロユニット (No. DNW107) の使用をおすすめします。
- ●走行後はモーターが加熱していますので、さわらないでください。
- ●モーターの回転を無理に止めないでください。大きな電流が流れて モーターや車体の電子回路、電池などの故障や破損の原因になります。
- ●モーターは消耗品です。下記の現象がでた場合は、モーターの寿命と 考えられますので早めに交換してください。
 - スピードが遅くなった。
 - 走行時間が短くなった。
 - 操縦に異常が出る。

下記ホームページアドレスから取扱説明書のオプションパーツリストをご覧ください。

http://www.dnano.jp/support/

※製品改良のため、予告なく仕様を変更する場合があります。 禁無断転載複製



61920803-1 PRINTED IN JAPAN

●ユーザー相談室直通電話 046-229-4115 お問い合わせは:月曜~金曜(祝祭日を除く)10:00~18:00

京商株式会社 〒243-0034 神奈川県厚木市船子153 DNW108-C01

X-SPEED MOTOR Type S No.DNW108

This high performance motor is developed for the exclusive use of dNano FX SERIES. The following are the points you should pay attention when using it.



- *Use the motor only for the dNaNo FX SERIES.
- *Before setting or removing the motor, please read instruction manual of dNaNo chassis in detail.
- *It is recommended to use the Ball Bearing Set (No.DNW101) and the Gyro Unit (No.DNW107) for faster driving.
- *Do not touch the motor after use, it is hot.
- *Do not stop the motor forcibly. It may cause the motor or the circuitry to break or malfunction.
- *The motor will need to be replaced every once in a while as it is an expendable part. When you notice the following symptoms, please consider replacing the motor with a new one.
- It slows down.
- The running duration becomes shorter.
- There is something unusual in the control of the car.

Please refer to the website below for the instruction manual and option parts list.

http://www.dnano.ip/support/

