




● 分解図

EXPLODED VIEW  
EXPLOSIONSZEICHNUNG  
VUE ECLATEE  
DESPIECE





ビス / Screws / Schraube /  
VIS / TORNILLOS



ボタンヘックスビス  
Button Hex Screw  
Inbus-Halbrundschrabe  
Vis BTR à tête ronde  
Button hex tornillo



|          |          |
|----------|----------|
| <b>A</b> | 2.6x12mm |
| <b>B</b> | 2.6x16mm |
| <b>C</b> | 3x6mm    |
| <b>D</b> | 3x8mm    |
| <b>E</b> | 3x10mm   |
| <b>F</b> | 3x12mm   |
| <b>G</b> | 3x15mm   |
| <b>H</b> | 3x18mm   |
| <b>I</b> | 3x20mm   |


サラヘックスビス  
F/H Hex Screw  
F/H Sechskantschraube  
Vis hexagonale F / H  
Tornillo hexagonal / F/H




|          |              |
|----------|--------------|
| <b>J</b> | 3x6mm (F/H)  |
| <b>K</b> | 3x8mm (F/H)  |
| <b>L</b> | 3x10mm (F/H) |
| <b>M</b> | 3x12mm (F/H) |
| <b>N</b> | 3x22mm (F/H) |




サーボセイバー / Servo Saver / Servo Saver  
Sauve-servo / Salvaservos




ステアリングサーボ / Steering Servo / Lenkservo  
Servo de direction / Servo de dirección




センターデフ / Center Diff. / Mitte Gear Differential  
Différentiel centre / Diferencial central




モーター / Motor / Motor  
Moteur / Motor



シャシー / Chassis / Das Chassis  
Chassis / Chasis




シャシー / Chassis / Das Chassis  
Chassis / Chasis






デフギヤ / Differential / Gear Differential  
Différentiel / Diferencial



ダンパー / Shock Absorber / Stoßdämpfer  
Amortisseur / Amortiguador

< フロント用 >  
< For Front >  
< Vorne >  
< Avant >  
< Delanteros >



< リヤ用 >  
< For Rear >  
< Hinten >  
< Arrière >  
< Traseros >