

Please read these instructions carefully before using this product.

SPEED HOUSE AA/AAA NiMH USB Charger

1.2V AA/AAA NiMH battery auto-cut quick charger



Instruction Manual
No. 71999

Thank you very much for purchasing the SPEED HOUSE AA/AAA NiMH USB Charger. For your safety, please carefully read this manual before use and follow the instructions correctly.

Safety Precautions

- Charger and batteries can be hot while charging. be careful not to burn yourself, and use the charger away from inflammables.
- Improper operation can damage the equipment and the batteries causing leak, intense heat and explosion.
- If you are not used to using rechargeable batteries, seek advice from experts to use them safely.

DANGER Failure to follow these instructions can result in high risk of death or injury.

- Use NiMH batteries having capacity of 700mAh or more, and charge them correctly.
- Do not use the charger for any purposes other than charging NiMH batteries.
- Do not insert needles or metal pieces into the charger or connect to the output terminals.
- Do not put the charger in water or salt water. Do not operate with wet hands or charge wet batteries.
- Do not disassemble or modify.
- Use USB compliant power source only. Never connect to a power supply with output voltage higher than 9V.

WARNING Failure to follow these instructions can result in high risk of death or injury.

- Make sure that the polarity is correct before inserting batteries.
- Do not cover the charger or battery with a towel or blanket.
- Do not charge near flammable materials or plastics that can ignite or deform from heat.
- Do not charge batteries when it is hot or immediately after use.
- Do not use the charger if you notice any abnormality.
- Do not charge batteries longer than 3 hours. If charging does not finish within 3 hours, stop charging and check batteries.
- Do not charge fully charged batteries.
- Do not use the charger in a car.

CAUTION Failure to follow these instructions may result in accidents, injury or damage.

- Charge batteries in an ambient temperature of -10°C - 40°C .
- Do not use under direct sunlight.
- Always monitor the charger while it is in operation.
- Do not use continuously.
- Always remove batteries after charging.
- Do not drop or apply an impact.
- Do not store in a damp or dusty environment.
- Keep out of reach of children.

